

Check to make sure that the spring is seated correctly on the shock.

Run zip ties through the holes in the spring hat and around the spring to prevent the spring from becoming unseated.



REAR SOLID AXLE SHOCK INSTALL

- 👉 The suspension has two sets of holes. The top set is for the Hot Rod or low ride height while the bottom set is for the Truck.
- 👉 If using the double adjustable shocks, attach them to the frame using the upper holes.